


Nexus Automatic System - Control Box Wiring Diagram - Gravity Fed Version



We recommend that all electric work on your Nexus Automatic System be done by a suitably qualified electrician. Always isolate the unit from mains electricity before carrying out any maintenance.

